



Liquid disinfectant concentrate based on aldehyde compounds (formaldehyde-free) for disinfecting surfaces and equipment

perform® classic concentrate GA

At a glance:

- Foam-free
- Excellent material compatibility
- Residue free rinsing
- Suitable for equipment disinfection (e.g. for CIP equipment)
- Efficacy tested to European norms

Applications

The product performance profile proves its suitability for use in industrial production areas (e.g. Pharma-cosmetic industry). perform® classic concentrate GA is foam-free and thus can also be used for equipment disinfection in pumping procedures (e.g. CIP equipment).

Instructions for use

Heavily contaminated surfaces are to be pre-cleaned if necessary. Prepare the required concentration of perform® classic concentrate GA working solution by dosing the required quantity of concentrate into water.

Apply the working solution to the surfaces to be disinfected:

- spray larger surfaces.
- place equipment in the working solution.
- wipe floor and work surfaces.
- For equipment and line systems, rinse pumped- through surfaces which come into contact with foodstuffs with an adequate quantity of potable water after expiry of the recommended contact time.

Microbiological effectiveness

perform® classic concentrate GA is bactericidal, fungicidal, virucidal (BVDV, Vaccinia).

Contact times / in-use concentrations

perform® classic concentrate GA already possesses a broad microbiological effectiveness at low in-use concentrations.

	15 Min.	30 Min.	60 Min.
bactericidal	1,5 % (15 ml/l)	1 % (10 ml/l)	0,75 % (7,5 ml/l)
fungicidal		3 % (30 ml/l)	2 % (20 ml/l)
levurocidal		1 % (10 ml/l)	0,75 % (7,5 ml/l)
virucidal (BVDV, Vaccinia)	0,5 % (5 ml/l) - 5 Min.		



Tested according to EN 1276, 13697.

Product data

Composition: 100 g contain: 10 g Glutaral.

Chemical / physical data:

Appearance:	clear, yellow liquid
Density at 20°C:	1,03 g/cm ³
Odour:	aldehyde like
Viscosity (DIN 53211):	< 15 S

perform[®] classic concentrate GA

Labelling according to EC Directives

- Xn: Harmful.
R20: Harmful by inhalation.
R37: Irritating to respiratory system.
R41: Risk of serious damage to eyes.
R42/43: May cause sensitization by inhalation and skin contact.
R52/53: Harmful to aquatic organisms, may cause long-term adverse effects in the aquatic environment.
S23: Do not breathe vapour.
S26: In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.
S35: This material and its container must be disposed of in a safe way.
S36/37/39: Wear suitable protective clothing, gloves (e.g made of butyl rubber) and eye/face protection.

Environmental information

schülke manufactures products economically and with advanced, safe and environmentally friendly production processes while at the same time maintaining our high quality standards.

Expert opinions and informations

Please visit our website for an overview of all available literature / reports on perform[®] classic concentrate GA: www.schuelke.com

For further information please contact your local representative or local offices.

Special notes

Use disinfectants safely. Always read the label and product information before use.

Forms of delivery / packaging units

Container sizes	Packaging units	Art. No.
10 L canister	1 x 10 L	148420
200 L drum	1 x 200 L	148421

Accessories / dosing aids

	Art. No.
10 L canister doser (20 ml/stroke)	117101
10 L canister tap	135501
10 L canister key	135810
200 L drum tap	117401

For detailed information on our dosing equipment, please request our complete overview of hygiene technology.



Schülke & Mayr GmbH is certified according to DIN EN ISO 9001, DIN EN ISO 14001 and DIN EN ISO 13485 (Reg.-No. 004567-MP23) and has a validated environmental system in accordance with the Eco Audit Regulation (Reg.-No. DE-150-00003).

Schülke & Mayr GmbH
22840 Norderstedt, Germany
Phone +49 (0) 40 - 521 00 - 0
Fax +49 (0) 40 - 521 00 - 318
www.schuelke.com
mail@schuelke.com

Schülke & Mayr UK Ltd.
1 Jenkin Road
GB-Sheffield S9 1AT
Phone +44 (0) 1142 - 54 35 - 00
Fax +44 (0) 1142 - 54 35 - 01
mail.uk@schuelke.com

Schülke & Mayr Ges.m.b.H
Seidengasse 9
1070 Wien, Austria
Phone +43 (0) 1 - 523 25 01 - 0
Fax +43 (0) 1 - 523 25 01 - 60
office@schuelke.at